

GFCI BREAKER INSTALLATION INSTRUCTIONS

- 1- MOVE HANDLE OF GFCI BREAKER TO "OFF"
- 2- PLUG-IN OR BOLT-ON GFCI INTO PANEL
- 3- CONNECT WHITE WIRE GFCI PIGTAIL TO PANEL NEUTRAL BAR
- 4- CONNECT GROUND WIRE OF THE SPA TO THE PANEL GROUND LUG
- 5- CONNECT WHITE WIRE OF THE SPA TO THE GFCI CONNECTOR MARKED "LOAD NEUTRAL"
- 6- CONNECT THE HOT RED AND BLACK WIRES OF THE SPA TO THE GFCI CONNECTORS MARKED "LOAD POWER"

NOTE: THE NEUTRAL WHITE WIRE OF THE SPA MUST BE CONNECTED TO THE GFCI CONNECTOR MARKED "NEUTRAL LOAD".